Electric Fail-Safe Valve

Automatically Closes Purge Valve in Case of Power Failure





EFS Valve shown with purge controller

Specifications:

Voltage: 12V DC, 24V DC and 100-240V AC **Frequency:** 50/60Hz **Power Draw:** 30-48 VA **Current Draw:** 0.3-0.2 A 75% Duty Rated

Valve Open-Close Time: 8 seconds from 0 to 90 degrees.

Fail-Safe Delay: EFS Valve starts closing 5 seconds after power loss

Housing: V0 self-extinguish class techno-polymer, water-tight

Protection Level: NEMA 4/4X IP65 IP67

Certifications: CEUL

Cover Type: UL 50

Ambient Temperature Range: -4 F to 131 F Auxiliary Contact Rating: 1A @ 30VDC/250VAC RESISTIVE

Protection Against Electrical Shock: Class I Cover Type: UL 50

Recommended Battery Check: Once per year, expected life time is 12-15 years

Fail-Safe Batteries: Rechargeable Nickel-Metal-Hydride battery pack that provides 400 charge/ discharge cycles. The batteries are automatically charged when the supply is connected

Models:

Models	Valve Diameter	
	inches	mm
EFS-07	3/4″	19.05
EFS-15	1-1/2″	38.1


Purge controller is required and included as part of valve kit.

LAKOS® is a trademark of Claude Laval Corporation

LAKOS is an active member of the U.S. Green Building Council LAKOS is a proud and contributing member of ASHRAE for over 30 years

EFS Features and Benefits:

- EFS closes purge valve in case of power failure
- Purges solids automatically eliminating manual purging
- Visual indicator on EFS provides easy-to-read current valve position
- Manual override for quick purge situations
- EFS features an electronic circuit that adjusts motor speed to keep cycle time constant, maintaining consistent purge durations
- Can be installed in combination with Solids Recovery Vessel
 (SRV-816 or SRV-833) for short-term conditions that require direct
 purging
- Actuator housing made of V0 self-extinguish material for fire safety
- EFS features a torque limiter circuit that protects motor from overcurrent or overtorque conditions



EFS Installation:

SEPARATOR

EFS and LAKOS Controller automatically purge separated solids from Separator's collection chamber at pre-determined time intervals – eliminating manual purging.

Contact LAKOS for EFS installation guide with more detailed specifications.



1365 N. Clovis Avenue • Fresno, California 93727 USA Telephone: (559) 255-1601 • Fax: (559) 255-8093 www.lakos.com • info@lakos.com